



| | |
|----------|--------------------------------------------|
| STA01570 | Flexvent Super with non-return (10 pc box) |
| STA09246 | Flexvent Super with non-return (1 piece) |
| STA10061 | Membrane FG/FB 100 Liter |
| STA10017 | Membrane FG/FB 200 Liter |
| STA10018 | Membrane FG/FB 300 Liter |
| STA10019 | Membrane FG/FB 400 Liter |
| STA10020 | Membrane FG/FB 500-600 Liter |
| STA10021 | Membrane FG/FB 800 Liter |
| STA10022 | Membrane FG/FB 1000 Liter |
| STA01934 | Membrane rupture sensor |
| STA07620 | Pall-ring container |
| STA01216 | Ball-valve for condenswater / drain tap |
| STA10036 | Measuring feet sensor 100-200 Liter |
| STA10037 | Measuring feet sensor 300-500 Liter |
| STA10038 | Measuring feet sensor 600-1000 Liter |
| STA10033 | Adjustable feet FG/FB 100-300 Liter |
| STA10035 | Adjustable feet FG/FB 400-1000 Liter |

| | | | | | | | | |
|------------------------------------------------------|---------|--------------------------------------------|--|----------------------------------------|---------|-----------------|--------|-----------|
| Description: Flamcomat vessel spareparts chart | | Remark: | | | | | | |
| | | Drawn: MH | | Date: 05-12-2017 | | | | |
| Material: | | Draw & general tolerance acc. ISO 8015 (E) | | Projection: | Format: | Scale: | Units: | |
| | | Form & orientation tolerance acc. ISO 1101 | | | A4 | 1:1 | mm | |
| Size: | Weight: | System of limits & fits acc. ISO 286 | | Progress level: Released | | | | |
| | | Code number: | | Tolerances unless otherwise specified: | | Drawing number: | | Revision: |
| | | | | | | 00087236 | | |